


EXTREME ACTIVE BRAKE WITH WIRING



Spring limit M170

Installation of this device leave to expert
He must know how to solder and disassemble airsoft gun
Never use soldering gun!

How connect device into the gun

- 1) Red thick cable lead to the positive pole of battery. Add fuse between battery and device. (not included in package)
 - 2) Black thick cable lead to the negative pole of battery
 - 3) Red thick cable lead to the positive pole of motor
 - 4) Black thick cable lead to the negative pole of motor.
 - 5) Blue thin cable lead to the one trigger connector in mechbox (no matter where).
 - 6) Blue thin cable lead to the one trigger connector in mechbox (no matter where).
- Be extra sure to connect the red and black wires appropriately, otherwise you will destroy device.

